

U/v Linear Birds – USB downlink LSB uplink				
AO-7	Down:	145.925	145.950	145.975
	Up:	432.175	432.150	432.125
AO-73	Down:	145.950	145.960	145.970
	Up:	435.150	435.140	435.130
CAS-4B	Down:	145.915	145.925	145.935
	Up:	435.290	435.280	435.270
EO-88	Down:	145.960	145.975	145.990
	Up:	435.045	435.030	435.015
UKUBE-1	Down:	145.930	145.940	145.950
	Up:	435.080	435.070	435.060
XW-2A	Down:	145.665	145.675	145.685
	Up:	435.050	435.040	435.030
XW-2B	Down:	145.730	145.740	145.750
	Up:	435.110	435.100	435.090
XW-2C	Down:	145.795	145.805	145.815
	Up:	435.170	435.160	435.150
XW-2D	Down:	145.860	145.870	145.880
	Up:	435.230	435.220	435.210
XW-2F	Down:	145.980	145.990	146.000
	Up:	435.350	435.340	435.330
V/u Linear Birds – USB downlink LSB uplink				
FO-29	Down:	435.800	435.850	435.900
	Up:	146.000	145.950	145.900
Fox-1E	Down:	435.760	435.775	435.790
	Up:	145.890	145.875	145.860
V/u FM Birds – 67.0 Hz tone on uplink				
SO-50 <i>(74.4 Hz On)</i>	Down:	436.805	436.795	436.785
	Up:	—	145.850	—
LilacSat2 <i>(no tone)</i>	Down:	437.210	437.200	437.190
	Up:	—	144.350	—
U/v & L/v FM Birds – 67.0 Hz tone on uplink				
AO-85	Down:	—	145.980	—
	Up:	435.160	435.170	435.180
AO-91	Down:	—	145.960	—
	Up:	435.240	435.250	435.260
AO-92	Down:	—	145.880	—
	U/ Up:	435.340	435.350	435.360
	L/ Up:	1267.320	1267.350	1267.380
Fox-1Cliff	Down:	—	145.920	—
	U/ Up:	435.290	435.300	435.310
	L/ Up:	1267.270	1267.300	1267.330
ESEO	Down:	—	145.930	—
	L/ Up:	1263.470	1263.500	1263.530

FUNCTION ITEMS	
BAND	Press [BAND/DWN] or [BAND/UP]
MODE	Press [MODE ◀] or [MODE ▶]
SPLIT	Press [F] , rotate [SEL] for "A/B, A=B, SPL" Press [C] for <i>Split</i> ; Press [C] again to cancel
STONE	Press [F] , rotate [SEL] for "RPT, REV, TON" Press [C] for <i>Tone</i> ; Press [C] again to cancel
PL TONE	Press [F] , rotate [SEL] for "RPT, REV, TON" Press/hold [C] for <i>Tone Freq</i> ; Rotate [SEL] for desired CTCSS; Press/hold [F] 1 sec to save
MEMORY	Press [F] , rotate [SEL] for "MW. MC, Tag" Press [A] for <i>MW</i> ; Rotate [SEL] for desired channel; Press/hold [A] 1 sec to store
M LABEL	Press [F] , rotate [SEL] for "MW. MC, Tag" Press [C] 1 sec for Menu #35 MEM TAG Press [SEL] ; Rotate [DIAL] to select letter; Rotate [SEL] for next letter; Repeat as needed Press/hold [F] 1 sec to save
MTUNE	In Memory Mode, rotate [DIAL] , as needed
POWER	Press [F] , rotate [SEL] for "PWR, MTR" Press [A] for <i>Power</i> ; Rotate [SEL] for L1-3 or H
BATT	Press [F] , rotate [SEL] for "CHG, VLT, DSP" Press [B] for <i>Display</i> ; Press [B] again to cancel
MENU ITEMS	
Press and hold [F] key for 1 sec Rotate [SEL] knob to select desired menu item Rotate [DIAL] knob to change value Press and hold [F] key for 1 sec to save, or [C] momentarily to cancel	
<i>Menu Item</i>	<i>Options</i>
04 AM&FM DL	ENABLE/DISABLE (DIAL)
07 ANTENNA	FRONT/REAR
10 BACKLIGHT	OFF/ON/AUTO
11 BATT-CHG	6/8/10 HOURS
15 COLOR	1=BLUE/2=AMBER/3=VIOLET
16 CONTRAST	1 ~ 12
29 FM MIC	0 ~ 100
30 FM STEP	5/6.25/10/12.5/15/20/25/50 KHZ
33 MAIN STEP	FINE/COARSE
34 MEMGROUP	OFF/ON/AUTO
35 MEM TAG	(ALPHA-NUMERIC)
45 SQL/RF-G	RF-GAIN/SQL
46 SSB MIC	0 ~ 100
47 SSB STEP	1/2.5/5 KHZ
48 TONE FREQ	(50 TONES)